

Product Name: **Fiber Optic Ceiling Display**

Product Code: **SFOCD**

Specification:

Size: 1.2m Diameter (approx.)
fixings.

Total Weight: 10.5kg (approx.)

Material: Wood, Compressed Wood Block and PMMA Fibre

LED: non – replaceable multi coloured LEDs

Input: 110-240V ~ 0.6A Max 50/60Hz

Output: 12V 2A

Please note: All weights and sizes are approximate

Contents:

1 x Ceiling Display

3 x Hook on Plate
Screws

1 x Remote Control (No battery included)

1 x Light Source Unit

1 x Power Adaptor

Tools required:

Suitable tools to attach

WARNING!

This item is to be installed by a competent, experienced installer only; we recommend that you use maintenance people experienced in setting up sensory rooms. At least three adults should assemble this item due to its size and weight.

This product must be attached to a ceiling that is strong enough to take its weight and is in good condition. We recommend regular checks to ensure that the item is firmly attached, it continues to work, and connections are not loose. It is the responsibility of the consumer to ensure the item is correctly attached and to perform regular checks.

Contains sequences of flashing lights which may affect individuals who are susceptible to photosensitive epilepsy or other photosensitivities.

Safety Warnings:

- Before setting up your light, ensure the product is not damaged. If any part of the product is damaged, do not attempt to assemble and use.
- Only use the adaptor and light source unit supplied with this product and no other adaptor or light source unit must be used.
- This is not a toy, keep away from children and pets during assembly.
- Do not operate in packaging
- Keep away from heat sources or naked flame
- Carry out regular checks to ensure fixings, fittings and installation has not become loose.
- Do not install on to a ceiling that cannot hold the weight of the item.
- Remove any light bulbs that are installed in the area where ceiling display is proposed to be mounted.

Before Setup

- Before you start, please read these instructions carefully and retain for future reference. Check the contents inside the packaging and ensure you have all the required parts listed and there are no missing parts. If any parts are missing **DO NOT** attempt to assemble the product.
- Carefully remove the product and each part from its packaging.
- Ensure a plug socket is within reachable distance, without stretching the wire too much.
- Before assembly, check to ensure the light source unit is working correctly, by attaching the bunch of gathered fibre optics to the front of the light source unit, tighten the screw to ensure it stays in place. Connect the power adaptor pin and plug the adaptor to the mains. Switch on to ensure lights turn on. If working correctly then disconnect everything and follow the setup instructions. If it does not work as intended, please contact Playlearn customer service on playlearn.com

Installation

1. Attach the light source to the ceiling light fibre optic end. Place the round end of the fibre optics into the round hole on the light source and screw tight so the fibre optics do not fall out.
2. Screw the light source box to the ceiling display.
3. Push the small black button on the back of the light source to turn it on; be careful not to look directly at the light source when it is turned on.
4. Screw the "hook on plate" to the ceiling, ensuring they are spaced the same distance as the chains on the ceiling display.
5. **CAUTION!** Assistant will be required to carry out this step. Carefully lift the entire ceiling display and attach each of the chains to the hook on the ceiling. The hook can be attached to any of the hoops on the hanging chains, to adjust the height and angle that the display sits at in the room.
6. Plug the light source adaptor in and secure all wires so that they do not dangle or otherwise present a hazard.

Please retain these instructions as it contains important information.

Made in China

PLAYLEARN
Know.Grow.Smile.

Playlearn USA Inc
1 South Liberty Dr, Stony Point
NY 10980, USA
playlearn.com

INSTRUCTION MANUAL

Before using our 7 colors light source, please read below instruction carefully. Any problems please contact with us.

7 colors Light source guarantee one year.

SAFE WARNING:

1. Check supply voltage, whether it matches light engine.
2. Prohibit to place the machine under rain or wet spot, prevent from causing troubles or danger of electric shock.
3. Light engine should be used in a draughty surrounding, not stack other things around it.






PARAMETER:

Supply voltage:
AC 100-240V /50-60Hz



Power: max 10W

Body Measurement: L110*W110*H90mm
(without connector)

Operation Illustration:



Program option:



bright down/ slow	bright up/quick	on/off
red	green	blue
yellow	sky blue	purple
white	warm white	mode
fade	breath	jump
twinkle speed	music 1	music 2