




# Hello!


I am your new 3 Foot Acrylic  
Hanging Bubble Wall





# CONTENTS

Make sure we're all in your box



**6** Adapter



**7** Remote



**8** Maintenance Hose  
*(manual pump and water pipe)*  
*For emptying and changing water -*  
*not needed for setup*



**9** Screws and Anchors



**10** Plastic Mount Guide

## OUR COMMITMENT TO YOU

Here at Playlearn, we have spent many years developing our Bubble Walls and Bubble Tubes to ensure they are simple to set up and trouble-free, so you can spend more time enjoying it and less time setting it up. We want you to love your Bubble Wall, so please let us know if any questions come up. Please email us at [support@playlearn.com](mailto:support@playlearn.com) and we will get back to you within 48 hours. The Bubble Wall is a delicate product and must be looked after and maintained to get optimal use. Any time maintenance is required (and certainly for emptying the water!), we recommend that two people do this together.



## DISTILLED WATER / REGULAR WATER

Although this product has been designed to work well with tap water, the product will need higher maintenance due to algae and the water becoming cloudy. The water will need changing approximately once every few months. By using distilled water, the water and product will stay clean for longer.

**THIS PRODUCT WILL USE APPROXIMATELY 2 GALLONS OF WATER**

## BRING A FRIEND ALONG

We recommend setting up with two people



# INSTRUCTIONS

To mount the wall panel, please choose a well-suited, supported wall. The panel is designed to rest on three screws which slide into the top back of the panel. If the screws and anchors provided aren't suited for your specific wall, please purchase proper anchors to support approximately 60lbs of weight.

1

Unpack all contents carefully and follow instructions step by step.

2

Fix bracket/screws to the wall at the designated height. Use provided pastic mount guide if necessary.

3

Fill the panel with water to about 10%.

4

Hang the Bubble Wall over the screws.

5

Connect the adaptor to the power port on the base of the Bubble Wall.

6

Test the product with the app or remote to ensure that it is all working properly (lights, pump, etc).

7

Fill Bubble Wall to the water level line.

8

Place the black lid onto the top of the Bubble Wall.

9

Place the customer support sticker on your Bubble Wall in case you need to reach out to us at any time.

10

## EMPTYING WATER FOR MAINTENANCE AND STORAGE

We have provided a maintenance hose to aid in emptying your Playlearn Bubble Wall. Attach the water pipe to the nozzle closer to the handle on the manual pump and place the other end of the pipe deep into the panel. Place a large bucket on the floor (or at a lower point than the end of the pipe) and start pumping until the water starts flowing.

## REMOTE

The remote operates the following way:

<b>Power</b>	Turns the product on and off
<b>Play/Pause</b>	Turns the light on and off
<b>Brightness</b>	Adjusts the brightness of the light
<b>Colors</b>	Changes the light to button color
<b>Auto</b>	Light will gradually change between all colors
<b>Jump 3/Jump 7</b>	Light will jump between red, green and blue / Light will jump between all 7 colors
<b>Fade 3/Fade 7</b>	Light will fade between red, green and blue / Light will fade between all 7 colors
<b>Flash</b>	Light will flash on and off
<b>Speed +/-</b>	Increases/decreases speed of the light changing

## SETTING UP THE APP

Search your phone's app store for "Playlearn".

Make sure your Bluetooth is "on". Download and open the app.

Press the menu icon on the top left corner.

Press "my devices" and select the device listed in the drop down until the connected link icon appears.

Your Bubble Wall must be turned "on" to establish a connection to the app.



# TROUBLE SHOOTING

**CRACKED PANEL** If your Bubble Tube is cracked, please contact customer support immediately.

**NO BUBBLES COMING OUT** If the pump is not making noise and the lights are not working, please check that you have completed the set up instructions. If the connection is correct, but the pump still isn't making noise, please contact customer support.

**SOME JETS ARE WORKING, SOME ARE NOT** On occasion, some of the air jets break in faster than the others. Since some are fully "broken into", the water is bypassing the jets that have not yet "broken in". If this occurs, follow these steps: Under each air jet, at the bottom of the tube, is a small dial that can be adjusted. Ensure that the dial under the non-working jets are open, by loosening them. Then, close the dials under the jets that are currently working by tightening them. This should stop around 90% of the bubbles. By doing this, pressure will be forced into the open jets, forcing the air bubbles to break through them. Please keep it like this for a few hours, to allow the jets to be fully "broken into". After a few hours, you can adjust all the dials back to a regular, even setting.

**REMOTE CONTROL NOT FUNCTIONING** The remote control is designed to change the colors of the lights and to change the light pattern. If the lights are on but they are not changing with the click of the remote control, try going a little closer to the base of the Bubble Tube. The red LED light turning on doesn't necessarily mean there is a good battery. If it does not work, please change the battery. If this fails to fix the problem, contact customer support for a replacement.

**NO POWER** First, touch the adaptor and see if it feels warm. If it is cold, contact customer support for a new adaptor. If the adaptor is warm, check the connection into the controller box (instruction #5) by removing and reinserting it and press the "on" button on the remote control. Check that the white wires coming out of the controller box are firmly connected to the plug and lights. If this still does not resolve the problem, please contact customer support.

**CAUTION** Always unplug the power before cleaning and handling. Disconnect and drain the water if storing away for an extended period of time. Do not operate with hot or ice-cold water. Do not lift, carry or pull the Bubble Tube by the power cord. Do not exceed the maximum voltage and wattage on adaptor.

**STILL STUCK?** Confused? Any further questions? Please contact customer support and one of our reps or techs would be happy to walk you through it. Call 888-575-0638 or email [support@playlearn.com](mailto:support@playlearn.com).



**WARRANTY**

**WARRANTY INFORMATION** Thank you for choosing Playlearn's Bubble Wall. All of our products are made with the highest quality materials. In the event that a product does not have our usual standard of excellence, we will repair or replace it, at our discretion, within 12 months from the date of purchase. A valid proof of purchase, with the purchase date clearly indicated, must be provided. Photos of defective merchandise may also be required to help us evaluate the cause of the defect.

**WATER DAMAGE** This product is not manufactured to withstand extreme temperatures. Improper storage that allows water to freeze within the Bubble Wall will cause damage and is not covered under the warranty. The use of "hard water" and/or caustic cleaners can affect the finish of the Bubble Wall. Failure to keep the unit clean, and use of additives/cleaners, will also void the warranty.

**NOT COVERED UNDER THE WARRANTY** The warranty will NOT cover cases of damage due to: inadequate care, immersion in water or improper installation, storage or maintenance.

This warranty also does not cover any additional charges or installation, removal, disposal, shipping costs or consequential damage associated with any warranty claim.





# You're All Set!

We are always here to support you -  
just reach out!

[www.playlearn.com](http://www.playlearn.com)

1 South Liberty Drive  
Stony Point, New York 10980

9:00 a.m. – 5:00 p.m.

[support@playlearn.com](mailto:support@playlearn.com)

(888) 575-0638